




# SLO 300/310

Outdoor light transmitter  
 Utomhusgivare för mätning av belysning  
 Außenhelligkeitsfühler  
 Sonde de lumière (extérieur)  
 Sensor de claridad externa  
 Sensore esterno di luminosità


# OFL-4185-000

Instruction  
 Montageanvisning  
 Bedienungsanleitung  
 Instructions d'installation  
 Instrucciones de empleo  
 Istruzioni per installazioni


1.



2.




3.




4.

## 4...20mA SLO 300



**UG=15...36 VDC**

## 0...10V SLO 310



**UG=15...36 VDC / 24 VAC**